


# INSTRUCTIONS:

1. PULL ON PIN TO RELEASE BARREL AND OPEN THE CYLINDER.
2. INSERT 8 SHOT RING CAPS INTO THE CYLINDER, SUCH THAT EACH CAP FITS ON THE PRONG.
3. PULL THE BARREL UP TO CLOSE THE CYLINDER



## **\* GUN SAFETY \***

- \* ALL GUNS CAN BE DANGEROUS IF NOT HANDLED WITH CARE.
- \* NEVER POINT A GUN AT ANYONE
- \* NEVER FIRE AT ANYTHING BUT A TARGET
- \* NEVER FIRE CAP GUNS INDOORS
- \* NOT SUITABLE FOR CHILDREN UNDER 8 YEARS OLD.
- \* DO NOT FIRE AT POINT BLANK RANGE
- \* DO NOT AIM AT EYES OR FACE.

## SAFETY INSTRUCTIONS

### WARNING:

CAPS AND TOY GUNS MAY BE HAZARDOUS IF MISUSED. THESE SHOULD ONLY BE USED UNDER ADULT SUPERVISION. DO NOT FIRE INDOORS. DO NOT FIRE NEAR EYES, EARS OR BODY. DO NOT CARRY CAPS LOOSE IN A POCKET. EACH CAP CONTAINS LESS THAN 0.002 GRAINS OF POWDER.